


PowerTrac³

Hardware Quick Installation Guide

1. Remove covers from the required battery posts.
2. Drill a 0.147" (#26 drill bit) hole 1/2" deep into the center of the battery posts.
3. Position the PowerTrac³ near the edge of battery, close to the opening in the truck and secure with cable ties. Do not mount directly to a steel battery case.
4. Attach the ring terminals to the battery posts using #10 sheet metal screws.
5. Once all wires are connected, assure that an LED is illuminated on the PowerTrac³.
6. Secure excess wires with wire ties and replace battery post covers.
7. Install the PowerTrac USB software and use in conjunction with a PowerTrac Link wireless communication module for PC-to-PowerTrac communication, intercell current calibration, parameter programming and data downloading. The software and manual can be downloaded at www.powerdesigners.com



This example battery is shown with 12 cells and one intercell strap between adjacent cells.
Actual battery configurations will vary.



Power Designers USA LLC
4005 Felland Drive, Suite 116 • Madison, WI 53718 USA
+1.608.231.0450 • www.powerdesigners.com

Power Designers USA LLC reserves the right to incorporate design and material changes without notice or obligation.
Design features, materials of construction and dimensional data are provided for your information only and should not be relied upon unless confirmed from Power Designers USA LLC.

COPYRIGHT © 2017 Power Designers USA LLC
014-000341-00_A